


Sony DSC-H5 Camera Setup

Menu Settings – the following settings are a good starting point

Metering	Center
White Balance	Auto
ISO	Auto or 800
P. Quality	Fine
AF Mode	Continuous
Digital Zoom	Off
Function Guide	On
Red Eye Reduction	Off
AF Illumination	Off
Auto Review	On
Expanded Focus	On
Flash Sync	Front
Steady Shot	Shooting
Conversion Lens	Off

Top Knob – these are the 3 recommended Modes to try

P: - Program Mode – set Flash Off, ISO 800

 - High Sensitivity Mode – turns flash Off, sets ISO to 1600

 - Scenery / Mountains – sets ISO to Auto